


HWH® AP43076 Leveleze® Indicator Light System for Hydraulic Switch Valves



Leveleze® Indicator Light System makes leveling easy. Avoid the confusion of looking at a level-bubble to figure which side or end of the trailer needs to be leveled.

1. You simply position the hydraulic switch as indicated by the “ON” light.
2. Activate pump switch until indicator light goes off. The microprocessor in the sensing unit will then direct you with next operation.
3. When all the lights are out the vehicle is level.



(On I-80, Exit 267 South) | 2096 Moscow Road | Moscow, Iowa 52760
Phone: (800)321-3494 or (563)724-3396 | Fax: (563)724-3408 | Web: www.HWH.com
Made in the USA

STRONG, RELIABLE, HYDRAULIC POWER