


BOX, CONTROL

FOR 625S SERIES, COMPUTER-CONTROLLED LEVELING SYSTEMS

(USE BEGINNING 2005)

625S SERIES



REPLACEMENT PARTS

ITEM	PART	DESCRIPTION
1	RAP91172	SENSING UNIT
2	RAP91932	CLEAR POLY COVER
3	RP92193	RETAINER SEAL ONE PER RP92193
4	SEE MR45.2005	FOR SENSING UNIT MOUNTING HARDWARE INFORMATION
	R90925	5 AMP FUSE
	R90927	10 AMP FUSE
	R90928	15 AMP FUSE

NOTE: FUSES ARE SOLD IN QUANTITIES OF FIVE.

EXISTING ASSEMBLY AP #	VARIABLES				REPLACEMENT ASSEMBLY PART #	ID DECAL PART #
	JACK STYLE	SUSPENSION	ROOMS	GLASS		
AP37629	SA	AIR - DUMP		SOUTH	RAP91810	AP37682
AP37682	SA	AIR - DUMP		PROG	RAP91810	AP37682
AP37703	SA	AIR - DUMP	3 OR 4	SOUTH	RAP91766	AP36921
AP37778	SA	AIR - DUMP	1 OR 2	WEST	RAP91764	AP36919
AP37784	SA	PROGRAMMABLE	3 OR 4	PROG	RAP91813	AP37784
AP38073	SA	AIR - DUMP	1, 2 OR 3 W/ STEP COVER	WEST	RAP92013	AP38073
AP38107	SA	SPRING	1 OR 2	NORTH	RAP91763	AP36918
AP38236	SA	AIR - DUMP	1 OR 2	EAST	RAP91764	AP36919
AP38247	SA	AIR - DUMP	3 OR 4	EAST	RAP93318	AP38247
AP39658	SA	SPRING	3 OR 4	SOUTH	RAP91765	AP36920
AP39890	SA	AIR - DUMP	*3 OR 4	WEST	RAP91766	AP36921
AP39936	SA	AIR - DUMP		EAST	RAP91810	AP37682
AP40215	SA	SPRING		NORTH	RAP91762	AP36917
AP40514	SA	SPRING	1, 2 OR 3 W/ STEP COVER	WEST	RAP92204	AP41004
AP40940	SA	AIR - DUMP		NORTH	RAP91810	AP37682
AP41004	SA	SPRING	1, 2 OR 3 W/ STEP COVER	PROG	RAP92204	AP41004
AP41034	SA	SPRING	4 OR 5 W/ STEP COVER	PROG	RAP92205	AP41034
AP41211	SA	REM. SENS. - DUMP		N/A	RAP92208	AP41211
AP41276	SA	REM. SENS. - DUMP	1 OR 2	N/A	RAP92209	AP41276
AP43159	SA	SPRING	3 OR 4	NORTH	RAP91765	AP36920
AP43478 - 24V	SA	REM. SENS. - SPRING		N/A	RAP92321	AP43478
AP44468 - 24V	SA	AIR - DUMP	1 OR 2	PROG	RAP92975	AP44468
AP47154	SA	SPRING		EAST	RAP91762	AP36917

* NOTE: AP39890 MUST HAVE ACCESSORY OR IGNITION POWER TO OPERATE THE ROOMS. THE REPLACEMENT BOX WILL OPERATE THE ROOMS IN ANY KEY POSITION.