

# ROOM EXTENSION ASSEMBLIES GUIDE PAGE "SHOW HAULER TRUCKS"

**PROCEDURE:**

1. Locate the HWH identification tag on the room extension mechanism to get the correct room extension part number.
2. Find the correct room extension part number in the left column below.
3. Refer to the proper parts page for general replacement parts information and item number arrangements.
4. Two cylinder room extensions with a synchronizing cylinder have two room extension part numbers. One is for the left assembly, one is for the right assembly. If the room extension assembly originally had one number, that number is listed with the new numbers.

<b>MECHANISM</b> <b>AP38944</b> <b>AP38945</b>	<b>UNIVERSAL LEVEL OUT - 30.0" STROKE (WITH SYNCHRONIZING CYLINDER) - AP39504 KIT</b>  <b>SEE MR41.2690 FOR DRAWING AND PARTS INFORMATION.</b> <b>CYLINDER ASSEMBLY</b> _____ <b>ITEM 1 - RAP92076 (30.5" STROKE) - REPLACES AP38072</b> <b>LIFT CYLINDER ASSEMBLY</b> _____ <b>ITEM 11 - RAP92260 (2.75" LIFT) - REPLACES AP38604</b> <b>SYNCHRONIZING CYLINDER</b> _____ <b>ITEM 3 - RAP92077 (10.540" STROKE) - REPLACES AP37881</b> <b>LIFT SYNCHRONIZING CYLINDER</b> _____ <b>ITEM 12 - RAP92316 - REPLACES AP38264</b> <b>TUBE KIT</b> _____ <b>ITEM 2 - RAP92079 - REPLACES AP38267</b> <b>HOSE ASSEMBLIES</b> _____ <b>ITEM 4 - RAP90872 (AP24632) ITEM 5 - RAP91421 (AP24818)</b>
--	---